

LASERWASH® M5 QUICK REFERENCE			
BUTTON	FUNCTION		
INFO	This key identifies current operating information for machine.		
ALT	This key allows alternate key usage.		
STOP	This key stops machine motion.		
YES/ON	This key provides a Yes and/or On answer or command.		
IO MON	This key begins Input and Output Monitor commands.		
NO/OFF	This key provides a No and/or Off answer or command.		
F	This key tells the machine to move bridge forward or go "up" in the menu.		
B	This key tells the machine to move bridge backward or go "down" in the menu.		
L	This key tells the machine to move bridge left.		
R	This key tells the machine to move bridge right.		
A	This key tells the arch to index (rotate).		
CLEAR	This key clears previous key strokes and to begin a new command.		
ENTER	This key performs an enter function that will terminate a command.		
INSTANT MODE		FLUID MODE	
SEQUENCE	FUNCTION	SEQUENCE	FUNCTION
0	RESET ARCH IMPACT	0	LPA-SPOT FREE
1	ISSUE WASH A (1)	1	LPA-SOAP 1
2	ISSUE WASH B (2)	2	LPA-SOAP 2
3	ISSUE WASH C (3)	3	LPA-WAX
4	ISSUE WASH D (4)	10	HPA-RINSE
11	ENTRANCE DOOR UP	11	HPA-SOAP 1
12	ENTRANCE DOOR DOWN	13	HPA-WAX
13	EXIT DOOR UP	14	HPA-DRYING AGENT
14	EXIT DOOR DOWN	20	PRODUCTIVITY-RINSE
20	MAINTENANCE/AUTOMATIC TOGGLE	21	PRODUCTIVITY-HP SOAP 1
91	CLOSE WASH	22	PRODUCTIVITY-HP WAX
92	OPEN WASH	23	PRODUCTIVITY-3X FOAM
99	CANCEL WASH	24	PRODUCTIVITY-DRYING AGENT
TEST MODE		25	PRODUCTIVITY-3X WATER BYPASS
0	AUTOMATIC BRIDGE SENSOR TEST	30	UBF-NO CHEMICAL
1	TEST LOAD VEHICLE	31	WHEEL CLEANER
2	ENCODER TEST	33	RUST INHIBITOR
4	SIGN TEST	40	GATLIN GUN-NO CHEMICAL
5	DOOR TEST	45	OverGlow Application
8	ANTI-KNOT TEST	46	OverGlow Purge
10	STAND ALONE DRYER TEST	96	M5 WEEP 3X
11	OBD DRYER TEST	97	M5 WEEP MAIN
31	WASH A (1) FLUID TEST	STATUS MODE	
32	WASH B (2) FLUID TEST	SEQUENCE	FUNCTION
33	WASH C (3) FLUID TEST	0	OVERALL STATUS
34	WASH D (4) FLUID TEST	1	ENTRY STATUS
35	WEEP TEST	2	WASH STATUS
41	SEND DAILY SALES REPORT	4	CONDUCTOR STATUS
42	SEND DAILY COUNTER REPORT	5	GANTRY LOCATION
43	SENT TECH EMAIL	11	SOAP HEATER STATUS
50	PING LOOP BACK	13	BAY TEMPERATURE
51	PING SELF	14	OUTSIDE TEMPERATURE
52	PING BRIDGE NODE	20	CARS TODAY
53	PING POWER NODE	30	EMAIL OVERALL STATUS
54	PING BAY NODE	31	EMAIL DNS LOOKUP ERRORS
58	PING ACTIVATION NODE	32	EMAIL CORRECT ERRORS
59	PING GATEWAY	33	EMAIL TIMEOUT ERRORS
60	PING ACCESS	MOTION MODE	
61	PING DNS	SEQUENCE	FUNCTION
63	PING GOOGLE	1	HOME POSITION
90	RESET CONDUCTOR	10	FULL CYCLE
91	RESET ACTIVATION NODE	11	BRIDGE CYCLE
92	RESET BRIDGE NODE	12	TROLLEY CYCLE
93	RESET PUMP NODE		
94	RESET BAY NODE		

